

## Installing a Paper Underlay on Your Smart Slate W200

An underlay is a sheet of paper with an icon strip that you place under the underlay cover on the workspace. You can customize the underlay and icon strip, and then print the underlay. To use a tool, touch the pen to the tool's icon on the icon strip.

- To print an underlay**
1. Press the SMART Board icon in your computer's notification area, and then select **Control Panel**.
  2. Press **SMART Hardware Settings** and if you have more than one SMART product connected, press **SMART Slate**.
  3. Select **Set Up Underlay and Icon Strip** from the first drop-down list.
  4. Select an existing underlay from the color scheme drop-down list.
  5. Press **Print**.  
The *Print* dialog box appears.
  6. In your printer preferences, select **landscape** orientation, and then print the underlay.

### NOTE

If you print the underlay in portrait orientation, your printer could scale the underlay to fit the page, making the underlay smaller than the slate workspace.

### To install the underlay

1. Trim the excess paper from the edges of the underlay.
2. Lift the underlay cover from the lower right corner with your fingers.
3. Slide the underlay beneath the underlay cover.
4. Lower the underlay cover.